



22. Front wheel assy



NO.	PART NO.	DESCRIPTION	QUANTITY
1	DS250.02.00.00.03	right knuckle	1
2	5787-M8x16	flange bolt M8x16	4
3	93-SW8	spring washer ? 8	4
4	95-W8	plane washer ? 8	4
5	E250.04.01.03.00	front right brake cylinder	1
6	JD0360008	outside bush . knuckle	2
7	3452.1-FB 47x28x7	grease seal FB 47x28x7	2
8	276-B6204	ball bearing 6204	2
9	JD0360007	inside bush . knuckle	2
10	70.3-M6x16	bolt M6x16	12
11	JD0360150	disc . front brake	2
12	E250.02.00.00.01C	knurled bolt . front wheel	8
13	JD0360200-EU	hub . front wheel	2
14	276-B6203	ball bearing 6203	2
15	3452.1-FB 40x25x6	grease seal FB 40x25x6	2
16	JD0360006	small bush . knuckle	2
17	95-W16	plane washer ? 16	2

22 front wheel assy



NO.	PART NO.	DESCRIPTION	QUANTITY
18	93-SW16	spring washer ? 16	2
19	9457-M16x1.5	slotted nut M16x1.5	2
20	91-CP4x40	cotter pin 4x40	2
21	JD0360010	hub cover . front wheel	2
22	E250.02.01.00.03	aluminum rim . front wheel	2
23	E250.02.01.00.02	front right highway tire , AT21x8-10	1
24	D650.03.02.00.02	hub nut	8
25	DS250.02.00.00.02	left knuckle	1
26	E250.04.01.02.00	front left brake cylinder	1